WARRANTY INFORMATION

11

COMPASS

HTTO A DESIGNATION

Jeep





WARRANTY COVERAGE AT A GLANCE

DESCRIPTION	1 Yr/ 15,000 km	1 Yr/ 30,000 km	2 Yr/ 40,000 km	3Yr/ 60,000 km	3 Yr/ 100,000 km
Basic Limited Warranty Coverage					
Anti-Corrosion Perforation Limited Warranty:					
Special Warranty Coverage					
* Selected Components 2 years / 40,000 km					
Commercial Warranty Coverage					

* Refer to "section 2.1 F" for coverage.

2

1. Your Rights Under Limited Warranty From FCA Ind 1.1. Incidental And Consequential Damages Not	ia4
Covered	4
2. What Is Covered Under Limited Warranty From FCA	1
India	5
2.1. Basic Limited Warranty	5
2.2. Corrosion/Perforation Warranty	
2.3. Spare Parts / Repair Warranty and Accessories	
Warranty	8
	0
3. What Is Not Covered	
3.1. Modifications Not Covered	
3.2. Environmental Factors Not Covered	
3.3. Maintenance Costs Not Covered	
3.4. Racing Not Covered	11
3.5. Certain Kinds Of Corrosion Not Covered	12
3.6. Other Exclusions	12
3.7. Total Loss, Salvage, Junk, Or Scrap Vehicles Not	
Covered	13
3.8. Restricted Warranty	13

4. Other Terms Of Your Warranties	14
4.1. Exchanged Parts May Be Used In Warranty	
Repairs	14
4.2. Pre-Delivery Service	
4.3. Production Changes	
5. How To Get Warranty Service	16
5.1. Where To Take Your Vehicle	16
6. How To Deal With Warranty Problems	18
6.1. Steps To Take	18
6.2. Helpful Addresses and Telephone Numbers	
7. Maintenance	20
7.1. General Information	20
8. Maintenance Schedules	26
8.1. 1.4L MAir Engine Service And Maintenance	
Schedule	26
8.2. 2.0L Diesel Service And Maintenance Schedule	31

1. Your Rights Under Limited Warranty From FCA India

FCA India Automobiles Private Limited, hereinafter referred to as FCA India, warrants to repair or replace at its discretion, parts of your vehicle determined by FCA India to be defective, in accordance with the terms contained in this booklet. FCA India neither assumes nor authorizes any other person to assume for it any other liability which may arise in connection with the use of the vehicle. Except for the limited warranties describer herein, FCA India does not provide any other warranty, whether express, implied, statutory, or otherwise. The limited warranties contained in this booklet are issued in Mumbai, and any claim relating to or arising out of the warranty terms herein shall be subject to courts of Mumbai, which shall have exclusive jurisdiction to entertain and adjudicate said claims.

YOUR RIGHTS UNDER LIMITED WARRANTY FROM FCA INDIA 3

1.1. Incidental And Consequential Damages Not Covered

The limited warranties described in this booklet do not cover any incidental or consequential damages related to your vehicle's failure, neither during the warranty period or afterward.

Such damages include, but are not limited to, the following:

- Lost time
- Inconvenience
- The loss of the use of your vehicle
- The cost of rental vehicles, gasoline, telephone, travel, or lodging
- The loss of personal or commercial property
- The loss of revenue
- Transportation and/or towing cost

4 WHAT IS COVERED UNDER LIMITED WARRANTY FROM FCA INDIA

2. What Is Covered Under Limited Warranty From FCA India

2.1. Basic Limited Warranty

A. Who Is Covered

You are covered by the Basic Limited Warranty if you are a purchaser for use of the vehicle. Basic Limited Warranty however is transferable to Second Owner.

B. What Is Covered

The Basic Limited Warranty covers the cost of all parts and labor needed to repair any defective item on your vehicle supplied by FCA India that is defective in material, workmanship or factory preparation, subject to the exclusions and limitations set forth in this booklet. These warranty repairs or adjustments, including all parts and labor connected with them will be made by an FCA Authorized Workshop (hereinafter referred to as "Authorized Workshop") at no charge, using new, reconditioned, or remanufactured parts depending on the part involved and approved by FCA India.

C. Items Covered by Other Warranties

The following items are covered by separate warranties offered by their makers. They are **not covered** by the Basic Limited Warranty:

- Tires
- Batteries

However the customer can approach an FCA Authorized Workshop who will facilitate claiming warranty of these parts.

D. When It Begins

The Basic Limited Warranty begins on either of the following dates, whichever is earlier:

- The date you take delivery of the vehicle.
- The date when the vehicle was first put into use for example, as a dealer "demo" or as a FCA India company vehicle.

E. When It Ends

The Basic Limited Warranty lasts for 36 months from the date it begins or for 100,000 km on the odometer, whichever occurs first.

However for the vehicles used for commercial applications (used for hire or those operating with yellow number plates) the Basic Limited Warranty shall be limited to three years / 60,000 km, whichever occurs earlier.

WHAT IS COVERED UNDER LIMITED WARRANTY FROM FCA INDIA 5

A very few components which are covered under Basic Limited Warranty have restricted warranties as mentioned below:

- Shock Absorbers, Catalytic Converter, DPF, DEF, Exhaust System, Chrome Plated Parts like Emblems, Front Grill, Lenses (Head Lamp, Fog Lamp, DRL, Tail Lamp), Mirrors – Internal & External Mirrors, Windshields, Backlit Glass, Sun Roof glass and Window Glasses, All Rubber Mounts, Suspension Mounts, Elastic Pads, Weather Strips, Mouldings-Interior & Exterior, All Interior Trims including Dashboard, Door trims, Headliner and Seat Fabric, Battery- AGM & EFB are covered for two years / 40,000 km, whichever occurs earlier.
- Wear and tear components like Clutch Disc, Flywheel -Facing wear, Brake Pad and Disc. Consumables – Fluids, AdBlue/ Urea and Filters, Fuses, Spark Plug, Coolant, Wheel Alignment, Wheel Balancing and Remote Key Batteries are not covered by Basic Limited Warranty.
- Wiper Blades are covered for six months / 5,000 km, whichever occurs earlier.

6 WHAT IS COVERED UNDER LIMITED WARRANTY FROM FCA INDIA

F. Registration and Operation Requirements

The Basic Limited Warranty covers your vehicle only if it is operated in the manner described in your Owner's Manual and maintained at a FCA Authorized Workshop.

2.2. Corrosion/Perforation Warranty

A. Who Is Covered

You are covered if you are a purchaser for use of the vehicle.

B. What Is Covered

This warranty covers the cost of all parts and labor needed to repair or replace any sheet metal panels that get holes from rust or other corrosion. If a hole occurs because of something other than corrosion, this warranty does not apply. Cosmetic or surface corrosion — resulting, for example, from stone chips or scratches in the paint — is not covered. For more details on what is not covered by this warranty, refer to "section 3.5".

C. How Long It Lasts

This warranty starts when your Basic Limited Warranty begins under "section 2.1. E".

For all panels, the limit is three years from the date it begins or for 100,000 km on the odometer, whichever occurs first.

2.3. Spare Parts / Repair Warranty and Accessories Warranty

Description of Coverage:

All the spare parts / repairs carried out on paid basis at FCA Authorized Workshop will be covered for six months / 10,000 km whichever occurs earlier from the date of repair.

WHAT IS COVERED UNDER LIMITED WARRANTY FROM FCA INDIA 7

All the FCA approved accessories installed by FCA Authorized Workshop will be covered for 12 months / 20,000 km whichever occurs earlier, from the installation date.

All the FCA approved accessories sold to the customer prior to vehicle delivery and installed by FCA Authorized Workshop will be covered for 12 months / 20,000 km whichever occurs earlier, from the date Basic Standard Warranty begins.

8 WHAT IS NOT COVERED

3. What Is Not Covered

3.1. Modifications Not Covered

A. Some Modifications Do Not Void the Warranties But Are Not Covered

Certain changes that you might make to your vehicle do not, by themselves, void the warranties described in this booklet. Examples of some of these changes are:

- Installing non-FCA components, or equipment, such as a non-FCA radio or speed control
- Using special non-FCA LLC fluids, materials, or additives that have the same specifications as recommended by FCA LLC.

NOTE:

If the above items do not meet FCA LLC's recommended specifications, your warranty will be void.

But your warranties do not cover any part that was not on your vehicle when it left the manufacturing plant or is not certified for use on your vehicle. Nor do they cover the costs of any repairs or adjustments that might be caused or needed because of the installation or use of non-FCA India, components, equipment, materials, or additives.

Performance or racing parts are considered to be non-FCA India parts. Repairs or adjustments caused by their use are not covered under your warranties.

Examples of the types of alterations not covered are:

- Installing accessories except for genuine FCA India/ MOPAR® accessories installed by Authorized Workshop;
- Applying non-approved rustproofing or other protection products; or

- Using any refrigerant that FCA India has not approved.
- Changing the vehicle's configuration or dimensions, such as converting the vehicle into a limousine or food service vehicle.

B. Modifications That WILL Void Your Warranties

These actions will void your warranties:

- Disconnecting, tampering with, or altering the odometer will void your warranties, unless your repairing technician follows the legal and / or FCA India requirements for repairing or replacing vehicles's odometers.
- Attaching any device that disconnects the vehicle's odometer will also void your warranties.
- Use of non-recommended fluids, gases, surface protection treatment, components and accessories.

WHAT IS NOT COVERED 9

3.2. Environmental Factors Not Covered

Your warranties do not cover damage caused by environmental factors such as airborne fallout, bird droppings, insect damage, chemicals, tree sap, salt, ocean spray, acid rain, and road hazards. Nor do your warranties cover damage caused by hailstorms, windstorms, tornadoes, sandstorms, lightning, floods, and earthquakes.

Your warranties do not cover conditions resulting from anything impacting the vehicle. This includes cracks and chips in glass, scratches and chips in painted surfaces, or damage from collision surfaces, or damage from collision.

10 WHAT IS NOT COVERED

The warranty expressly excludes the slight irregularities not recognized as affecting the function or quality of the vehicle or parts. Such as any and all characteristic / behavioral qualities of the vehicle perceived by the customer, do not affect the performance of the vehicle including slight noise or vibration and characteristic appearing only under particular conditions or items considered characteristic of the vehicle.

3.3. Maintenance Costs Not Covered

Your warranties do not cover the costs of repairing damage caused by poor or improper maintenance. Nor do they cover damage caused by the use of contaminated fuels, or by the use of fuels, oils, lubricants, cleaners or fluids other than those recommended in your Owner's Manual.

The warranties do not cover the costs of your vehicle's normal or scheduled maintenance — the parts and services that all vehicles routinely need.

Some of these parts and services, which your warranties do not cover, include:

- Lubrication
- Engine tune-ups
- Replacing filters, coolant, spark plugs, or fuses, unless those costs result from a covered repair
- Cleaning and polishing
- Wheel alignment and wheel balancing during maintenance
- Top-up of fluids, AdBlue/Urea and consumables

3.4. Racing Not Covered

Your warranties do not cover the costs of repairing damage or conditions caused by racing, nor do they cover the repair of any defects that are found as the result of participating in a racing event.

2019 JEEP M6 GW INDIA.book Page 11

3.5. Certain Kinds Of Corrosion Not Covered

Your warranties do not cover the following:

- · Corrosion caused by accident, damage, abuse, or vehicle alteration
- Surface corrosion caused by such things as industrial fallout, sand, salt, hail, flood, and stones
- Corrosion caused by the extensive or abnormal transport of caustic materials like chemicals, acids, and fertilizers
- · Corrosion of special bodies, body conversions, or equipment that was not on your vehicle when it left the manufacturing plant or supplied by FCA India

3.6. Other Exclusions

Your warranties do not cover the costs of repairing damage or conditions caused by any of the following:

- Fire, flood, theft, or accident
- Abuse or negligence

WHAT IS NOT COVERED 11

- Misuse for example, driving over curbs or overloading
- Driving under severe conditions such as unpliable or water logged roads
- Tampering with the emission systems, or with a part that could affect the emission systems
- Use of used parts, even if they were originally supplied by FCA India (however, authorized FCA Inda or Mopar remanufactured parts are covered)
- · Windshield or rear window damage from external objects
- Any changes made to your vehicle that do not comply with FCA India
- Using any fluid that does not meet the minimum recommendations in your Owner's Manual

12 WHAT IS NOT COVERED

3.7. Total Loss, Salvage, Junk, Or Scrap Vehicles Not Covered

A vehicle has no warranty coverage of any kind if:

- The vehicle is declared to be a total loss by an insurance company.
- The vehicle is rebuilt after being declared to be a total loss by an insurance company.
- The vehicle is issued a certificate of title indicating that it is designated as "salvage", "junk", "rebuilt", "scrap".

FCA India will deny warranty coverage without notice if it learns that a vehicle is ineligible for coverage for any of the above reasons.

3.8. Restricted Warranty

FCA India may restrict the warranty on your vehicle if the vehicle is not properly maintained, or if the vehicle is abused or neglected, and the abuse or neglect interferes with the proper functioning of the vehicle. If the warranty is restricted, coverage may be denied or subject to approval by FCA India before covered repairs are performed.

4. Other Terms Of Your Warranties

4.1. Exchanged Parts May Be Used In Warranty Repairs

In the interest of customer satisfaction, FCA India may offer exchange service on some vehicle parts. This service is intended to reduce the amount of time your vehicle is not available for your use because of repairs. Parts used in exchange service may be new, remanufactured, reconditioned, or repaired, depending on the part involved.

All exchange parts that might be used meet FCA India standards, and have the same warranties as new parts.

OTHER TERMS OF YOUR WARRANTIES 13

Examples of the kinds of parts that might be serviced in this way are:

- Engine Assemblies
- Transmission Assemblies
- Instrument Cluster Assemblies
- Radios, Tape, CD and DVD Players
- Speedometers
- Powertrain Control Module (PCM)

To help control suspected ozone depleting agents, applicable law requires the capture, purification, and reuse of automotive air conditioning refrigerant gases. As a result, a repair to the sealed portion of your air conditioning system may involve the installation of purified reclaimed refrigerant.

14 OTHER TERMS OF YOUR WARRANTIES

4.2. Pre-Delivery Service

A defect in or damage to the mechanical, electrical, sheet-metal, paint, trim, and other components of your vehicle may have occurred at the factory or while it was being shipped to the dealer or as a result of other external factors.

Such a defect or damage is usually detected and corrected at the factory. In addition, dealers must inspect each vehicle before delivery. They repair any defects or damage detected before the vehicle is delivered to you.

4.3. Production Changes

FCA India and its dealers reserve the right to make changes in vehicles built or sold by them at any time without incurring any obligation to make the same or similar changes on vehicles previously built or sold.

5. How To Get Warranty Service

5.1. Where To Take Your Vehicle

A. In Your Country

Warranty service must be done by an Authorized Workshop. We strongly recommend that you take your vehicle to your selling dealer. He/she knows you and your vehicle best, and is most concerned that you get prompt and high quality service.

B. In A Foreign Country

If you are traveling temporarily outside your country and your vehicle remains registered in your country:

• You should take your vehicle to an Authorized Workshop. They should give you the same warranty service you receive in your country.

HOW TO GET WARRANTY SERVICE 15

- If the Authorized Workshop charges you for repairs which you feel should be covered under your warranty, please get a detailed receipt for the work done. Make sure that this receipt lists all warranty repairs and parts that were involved. (This receipt will be similar to the one used by the Workshop who normally services your vehicle.)
- When your vehicle returns to your country contact your Authorized Repairer for reimbursement consideration. You will normally need to provide a copy of the receipt, your vehicle registration and any other relevant documents.
- Reimbursement will not be considered if the vehicle does not return to the country of registration.

16 HOW TO GET WARRANTY SERVICE

C. If You Move:

If you move to another country, be sure to contact the FCA India Customer Relations and the customs department of the destination country before you move. Vehicle importation rules vary considerably from country to country. You may be required to present documentation of your move to FCA India in order to continue your warranty coverage. You may also be required to obtain documentation from FCA India in order to register your vehicle in your new country.

D. Notice:

If your vehicle is registered outside of the market the vehicle was built for and you have not followed the procedure set out above, your vehicle will no longer be eligible for warranty coverage of any kind. Vehicles registered to United States Government officials or Military personnel on assignment outside of the US will continue to be covered.

6. How To Deal With Warranty Problems

6.1. Steps To Take

A. In General

Normally, warranty problems can be resolved by your dealer's service department. That is why you should always talk to your dealer's service manager first. But if you are not satisfied with the response to your problem, FCA India recommends the following:

- Step 1: Discuss your problem with the Dealer Principal or General Manager of the dealership.
- Step 2: If your dealership still cannot resolve the problem, contact the FCA India Customer Relations address in "section 6.2".

HOW TO DEAL WITH WARRANTY PROBLEMS 17

B. What FCA India Will Do

Once you have followed the two steps described in "section 6.1 A", a FCA India representative will review your situation. If it is something that FCA India can help you with, FCA India will provide your dealer with all the information and assistance necessary to resolve the problem. Even if FCA India cannot help you, FCA India will acknowledge your contact and explain FCA India's position.

18 HOW TO DEAL WITH WARRANTY PROBLEMS

6.2. Helpful Addresses and Telephone Numbers

Here are the addresses and telephone numbers of the FCA India Customer Relations that can help you wherever you happen to be. Contact the one that covers your area:

FCA India Automobiles Private Limited

Registered Office: Office No. 401A, Giga Space IT Park, Delta – I, Viman Nagar, Pune Nagar Road, Pune – 411014, Maharashtra, India

7. Maintenance

7.1. General Information

It is your responsibility to properly maintain and operate your new vehicle. You must follow the maintenance schedule provided in this manual. Regular, scheduled maintenance is essential to trouble-free operation. If there is a dispute between you and your dealer concerning your maintenance of your vehicle, FCA India will require you to provide proof that your vehicle was properly maintained.

For your convenience, FCA India has prepared a Maintenance Log for you. You should use this Maintenance Log to keep track of scheduled maintenance, either by routinely having the repairs entered in your Maintenance Log, or by keeping receipts or other documentation of work you have had done on your vehicle in your Maintenance Log.

MAINTENANCE 19

A. Where To Go For Maintenance

FCA India recommends that you return to the dealer from whom you bought your vehicle for all maintenance service both during and after the warranty periods. Although you can get warranty service from any dealer who sells your particular make, returning to your selling dealer will help ensure that all your service needs are met and that you're completely satisfied.

FCA Authorized Workshop's technicians are specifically trained to proficiently perform maintenance and repair procedures on your vehicle.

FCA Authorized Workshops will help ensure that all your service needs are met and that you are completely satisfied. FCA India strongly recommends you use genuine FCA India/Mopar parts to maintain your vehicle.

20 MAINTENANCE

B. Oil Change Indicator System — If Equipped

The Scheduled Maintenance services listed in this manual must be done at the times or kilometers specified to protect your vehicle warranty and ensure the best vehicle performance and reliability. More frequent maintenance may be needed for vehicles in severe operating conditions, such as dusty areas, frequent short trips, trailer tow and extremely hot or cold ambient temperatures. Inspection and service should also be done any time a malfunction is suspected. The oil change indicator system will remind you that it is time to take your vehicle in for scheduled maintenance. On instrument cluster display equipped vehicles "Oil Change Required" will be displayed in the instrument cluster, indicating that an oil change is necessary.

NOTE:

The oil change indicator message will not monitor the time since the last oil change, Change your vehicle's oil if it has been twelve months since your last oil change even if the oil change indicator message is NOT illuminated.

- Change your engine oil more often if you drive your vehicle off-road for an extended period of time.
- Under no circumstances should oil change intervals exceed 15,000 km or 12 months, whichever comes first.

At Each Stop for Fuel

Check the engine oil level about five minutes after a fully warmed engine is shut off. Checking the oil level while the vehicle is on level ground will improve the accuracy of the oil level reading. Add oil only when the level is at or below the ADD or MIN mark.

Check the windshield washer solvent and add if required.

Check and top-up AdBlue/ Urea if required as indicated by the LED and or message on the instrument cluster.

Once A Month

- Check tire pressure and look for unusual wear or damage.
- Inspect the battery and clean and tighten the terminals as required.
- Check the fluid levels of coolant reservoir, brake master cylinder, power steering (if equipped) and transmission and add as needed.
- Check all lights and other electrical items for correct operation.

Oil Change Indicator Reset — If Equipped

The vehicle is equipped with an engine oil change indicator system. The "Oil Change Required" message flashes in the instrument cluster display for approximately ten seconds after a single chime has sounded, to indicate the next scheduled oil change interval. The engine oil change indicator system is duty cycle based, which means the engine oil change interval may fluctuate depending upon your personal driving style. Unless reset, this message continues to display each time you turn the ignition switch to the ON/RUN position. To turn off the message temporarily, press and release the Menu button. To reset the oil change indicator system (after performing the scheduled maintenance) perform the following procedure:

- 1. Turn the ignition switch to the ON position. Do not start the engine.
- 2. Fully depress the accelerator pedal slowly three times within 10 seconds.
- 3. Turn the ignition switch to the LOCK position.

NOTE:

• If the indicator message illuminates when you start the vehicle, the oil change indicator system did not reset. If necessary, repeat this procedure.

MAINTENANCE 21

22 MAINTENANCE

WARNING!

- You can be badly injured working on or around a motor vehicle. Do only service work for which you have the knowledge and the right equipment. If you have any doubt about your ability to perform a service job, take your vehicle to a competent mechanic.
- Failure to properly inspect and maintain your vehicle could result in a component malfunction and effect vehicle handling and performance. This could cause an accident.
- Failure to follow these instructions may result in possible serious or fatal injury.

CAUTION!

Failure to perform the required maintenance items may result in damage to the vehicle.

CAUTION! (Continued)

• Proper operation of four-wheel drive vehicles depends on tires of equal size, type and circumference on each wheel. Any difference in tire size can cause damage to the transfer case. Tire rotation schedule should be followed to balance tire wear.

C. Owner Service Policy

As the owner of a new FCA Vehicle you are entitled for following two free services from the date of delivery of the vehicle:

- First Service At 7,500 km / six months (whichever is earlier for 1.4 L Petrol)
- First Service At 5,000 km / six months (whichever is earlier for 2.0L Diesel)
- Second Service At 15,000 km / one year (whichever is earlier)

On presentation of relevant proof the service shall be performed by any FCA Authorized Workshop without labor charges. All the filters, fluid, AdBlue / Urea, consumables, components, wheel alignment, wheel balancing etc. required for carrying out service will be replaced on chargeable basis. Also any additional repair arising out of negligence, accident or improper use will be carried out on chargeable basis (Labor and Parts).

MAINTENANCE 23

All remaining services at stipulated kilometers / mileage will be chargeable basis even if the vehicle is under warranty, and shall be borne by the customer and availed at any FCA Authorized Workshop.

24 MAINTENANCE

D. Maintenance Log

Inspection and service should also be performed anytime a malfunction is observed or suspected. Retain all receipts.

1st Free Service	Dealer	2nd Free Service	Dealer	3rd Service	Dealer	4th Service	Dealer
Date	km	Date	km	Date	km	Date	km
5th Service	Dealer	6th Service	Dealer	7th Service	Dealer	8th Service	Dealer
Date	km	Date	km	Date	km	Date	km
9th Service	Dealer	10th Service	Dealer	11th Service	Dealer	12th Service	Dealer
Date	km	Date	km	Date	km	Date	km
13th Service	Dealer	14th Service	Dealer	15th Service	Dealer	16th Service	Dealer
Date	km	Date	km	Date	km	Date	km

8. Maintenance Schedules

Service under the terms of warranty at the stipulated km and time including the first service at 5,000 km or six months and thereafter every 15,000 km / One year (whichever is earlier) for 2.0L Diesel models.

MAINTENANCE SCHEDULES 25

First service at 7,500 km or six months and thereafter every 15,000 km / One year (whichever is earlier) for 1.4L Petrol models.

Inspection and service should also be performed anytime a malfunction is observed or suspected. You must retain all receipts of work you have had done on your vehicle.

Years:	6 months	1	2	3	4	5	6	7	8	9	10	#10	11	12	13	14	15	16
Kilometers or time passed (whichever comes first)	7,500	15,000	30,000	45,000	60,000	75,000	90,000	105,000	120,000	135,000	150,000	#240,000	165,000	180,000	195,000	210,000	225,000	240,000
Check and top up Engine Oil level ††	Х																	
Change the Engine Oil and Engine Oil Filter ††		х	х	х	х	х	х	х	х	х	х		х	х	х	Х	х	х
Replace Air Filter Element *		Х	Х	Х	Х	Х	Х	Х	Х	Х	Х		Х	Х	Х	Х	Х	Х

8.1. 1.4L MAir Engine Service And Maintenance Schedule

Years:	6 months	1	2	3	4	5	6	7	8	9	10	#10	11	12	13	14	15	16
Kilometers or time passed (whichever comes first)	7,500	15,000	30,000	45,000	60,000	75,000	90,000	105,000	120,000	135,000	150,000	#240,000	165,000	180,000	195,000	210,000	225,000	240,000
Replace Petrol Fuel Filter — if equipped		х	х	х	х	х	х	х	х	Х	х		х	х	х	х	х	х
Replace Pollen or HECA Filter		Х	Х	Х	Х	Х	Х	Х	Х	Х	Х		Х	Х	Х	Х	Х	Х
Replace Spark Plugs			Х		Х		Х		Х		Х			Х		Х		Х
Inspect and Replace PCV Valve if necessary					х				х					х				х
Inspect cooling system hoses and connections for leakage		х	х	х	х	х	х	х	х	х	х		х	х	х	х	х	х
Check and top up Engine Coolant	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х		Х	Х	Х	Х	Х	Х
Flush and replace Engine Coolant												X#						
Check and top up Brake / Clutch Fluid	х	х		х		х		х		х			х		х		х	
Replace Brake/ Clutch Fluid			Х		Х		Х		Х		Х			Х		Х		Х
Check and top up Fluid level - Wind Screen Washer	х	х	х	х	х	х	х	х	х	Х	х		х	х	х	х	х	х

2019 JEEP M6 GW INDIA.book Page 27

6 Years: 1 2 3 4 5 6 7 8 9 10 #10 11 12 13 14 15 16 months #240,000 120,000 135,000 150,000 165,000 180,000225,000 240,000 105,000 195,000 210,00015,000 90,000 30,000 45,000 60,000 75,000 7,500 Kilometers or time passed (whichever comes first) Х Х Х Х Х Х Inspect accessory drive belt tension Х Х Х Х Х Х Х Replace Accessory Drive Belt(s) ** Х Х Х Replace Timing Belt Drive Kit ** Х Х Х Inspect the Front Brake Pads and Х Х Х Х Х Х Х Х Х Х Х Х Х Х Х Х Discs, replace if necessary Inspect Rear Brake Pads and Discs, Х Х Х Х Х Х Х Х Х Х Х Х Х Х Х Х replace if necessary Inspect the Front Suspension, Tie Rod Ends and Boot Seals, replace if Х Х Х Х Х Х Х Х Х necessary Inspect Transmission for any Oil Х Х Х Х Х Х Х Х Х leaks Inspect Transmission Oil level, top up Х Х Х Х Х Х Х Х Х if necessary Inspect the CV Joints Х Х Х Х Х Х Х Х Х Х Х Х Х Х Х Х Х Inspect Exhaust System Х Х Х Х Х Х Х Х

Years:	6 months	1	2	3	4	5	6	7	8	9	10	#10	11	12	13	14	15	16
Kilometers or time passed (whichever comes first)	7,500	15,000	30,000	45,000	60,000	75,000	90,000	105,000	120,000	135,000	150,000	#240,000	165,000	180,000	195,000	210,000	225,000	240,000
Check Underbody Protection, Pipes and Hoses (Exhaust-Fuel-Brakes), Rubber Parts (Boots, Sleeves, Bushes, etc), Oil Leakage and Coolant Leakage	x	x	х	х	x	х	x	x	х	x	x		х	х	х	х	x	х
Inspect all Door Latches for presence of Grease, reapply if necessary	х	х	х	х	х	х	х	х	х	х	х		х	Х	Х	Х	х	х
Check all Lights and other Electrical items for correct operation	х	х	х	х	х	х	х	х	х	х	х		х	Х	Х	Х	х	Х
Check Tire conditions / wear and adjust pressure if required	х	х	х	х	х	х	х	х	х	х	х		х	Х	Х	Х	х	Х
Rotate Tires		Х	Х	Х	Х	Х	Х	Х	Х	Х	Х		Х	Х	Х	Х	Х	Х
Check & Adjust Four Wheel Alignment ##	х	х	х	х	х	х	х	х	х	х	х		х	х	Х	х	х	Х

2019 JEEP M6 GW INDIA.book Page 29

MAINTENANCE SCHEDULES 29

Years:	6 months	1	2	3	4	5	6	7	8	9	10	#10	11	12	13	14	15	16
Kilometers or time passed (whichever comes first)	7,500	15,000	30,000	45,000	60,000	75,000	90,000	105,000	120,000	135,000	150,000	#240,000	165,000	180,000	195,000	210,000	225,000	240,000
Check Engine Control System Operation (Using Electronic Diagnostic Interface)	х	х	х	х	х	х	х	х	х	х	х		х	х	х	х	х	х
Check and top-up battery demineralised water	х	х	Х	х	Х	Х	Х	х	х	х	х	х	х	Х	Х	Х	х	Х

†† Change Engine Oil and Engine Oil Filter at every 10,000 km / one year whichever is earlier if using your vehicle under any of the severe duty conditions: Heavy, Urban, Short Trip.

* Regardless of the km covered, Air filter should be replaced earlier if operating under Dusty Conditions.

(**) Regardless of the distance covered, Timing and Accessory Belts must be changed every four years for particularly demanding use (cold climates, city driving, long periods of idling) or at least every five years. Under no circumstances should these intervals be exceeded.

It is recommended to flush and replace the engine coolant at the interval of 10 years/240,000 km or whichever comes first.

Possible refill of the coolant may need to be completed using FCA recommended coolant after system integrity confirmations.

Wheel alignment & Wheel balancing on chargeable basis.

Check and top-up battery demineralised water every six months.

Note : Maintenance not required for AGM Battery.

Before long journeys, check the following and top up if necessary:

1. Engine oil level

2. Engine coolant fluid level

30 MAINTENANCE SCHEDULES

8.2. 2.0L Diesel Service And Maintenance Schedule

Years:	6 months	1	2	3	4	5	6	7	8	9	10	#10	11	12	13	14	15	16
Kilometers or time passed (whichever comes first)	5,000	15,000	30,000	45,000	60,000	75,000	90,000	105,000	120,000	135,000	150,000	#240,000	165,000	180,000	195,000	210,000	225,000	240,000
Check Engine Oil level ††	Х																	
Change the Engine Oil and Engine Oil Filter ††		х	х	х	х	х	х	х	х	х	х		х	х	Х	х	х	х
Replace Air Filter Element *		Х	Х	Х	Х	Х	Х	Х	Х	Х	Х		Х	Х	Х	Х	Х	Х
Replace Diesel Filter		Х	Х	Х	Х	Х	Х	Х	Х	Х	Х		Х	Х	Х	Х	Х	Х
Replace Pollen or HECA Filter		Х	Х	Х	Х	Х	Х	Х	Х	Х	Х		Х	Х	Х	Х	Х	Х
Check and, if necessary, top-up additive for emissions reduction (AdBlue/ Urea) if equipped, at all stops.	х	х	x	x	x	x	x	x	x	x	x	x	x	x	х	х	x	x
Inspect cooling system hoses and connections for leakage		х	х	х	х	х	х	х	х	х	х		х	х	Х	Х	х	х
Check and top up Engine Coolant	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х		Х	Х	Х	Х	Х	Х
Flush and replace Engine Coolant												X#						

Years:	6 months	1	2	3	4	5	6	7	8	9	10	#10	11	12	13	14	15	16
Kilometers or time passed (whichever comes first)	5,000	15,000	30,000	45,000	60,000	75,000	90,000	105,000	120,000	135,000	150,000	#240,000	165,000	180,000	195,000	210,000	225,000	240,000
Check and top up Brake / Clutch Fluid	х	х		х		х		х		х			х		х		х	
Replace Brake/ Clutch Fluid			Х		Х		Х		Х		Х			Х		Х		Х
Check and top up Fluid level - Wind Screen Washer	х	х	х	х	х	х	х	х	х	х	х		х	х	х	х	х	х
Inspect accessory drive belt tension		х	х	х	х	х		х	х	х	х		х		х	х	х	х
Replace Timing Belt Drive Kit **							Х							х				
Replace Accessory Drive Belt(s) **							Х							Х				
Inspect the Front Brake Pads and Discs, replace if necessary		х	х	х	х	х	х	х	х	х	х		х	х	х	х	х	х
Inspect Rear Brake Pads and Discs, replace if necessary		х	х	х	х	х	Х	х	х	х	х		х	х	х	х	х	х

Years:	6 months	1	2	3	4	5	6	7	8	9	10	#10	11	12	13	14	15	16
Kilometers or time passed (whichever comes first)	5,000	15,000	30,000	45,000	60,000	75,000	90,000	105,000	120,000	135,000	150,000	#240,000	165,000	180,000	195,000	210,000	225,000	240,000
Inspect the Front Suspension, Tie Rod Ends and Boot Seals, replace if necessary	х		x		x		х		х		х			х		х		х
Inspect Transmission for any Oil leaks	х		х		х		х		х		х			х		Х		х
Inspect Transmission Oil level, top up if necessary	х		х		х		х		х		х			х		Х		х
Inspect the Rear Axle Fluid, top up if necessary	х		х		х		х		х		х			х		Х		х
Inspect Transfer case Oil Level, top up if necessary (if equipped)	Х		х		х		х		х		х			х		х		х
Inspect the CV Joints	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х		Х	Х	Х	Х	Х	Х
Inspect Exhaust System			Х		Х		Х		Х		Х			Х		Х		Х

Years:	6 months	1	2	3	4	5	6	7	8	9	10	#10	11	12	13	14	15	16
Kilometers or time passed (whichever comes first)	5,000	15,000	30,000	45,000	60,000	75,000	90,000	105,000	120,000	135,000	150,000	#240,000	165,000	180,000	195,000	210,000	225,000	240,000
Check Underbody Protection, Pipes and Hoses (Exhaust- Fuel-Brakes), Rubber Parts (Boots, Sleeves, Bushes, etc), Oil Leakage and Coolant Leakage	x	x	x	x	x	x	x	x	x	x	x		x	x	х	х	x	x
Inspect all Door Latches for presence of Grease, reapply if necessary	х	х	х	х	х	х	х	х	x	х	х		х	х	х	х	х	х
Check all Lights and other Electrical items for correct operation	х	х	х	х	х	х	х	х	х	х	х		Х	х	х	Х	х	х
Check Tire conditions / wear and adjust pressure if required	х	х	х	х	х	х	х	х	х	х	х		х	х	х	Х	х	х
Rotate Tires		Х	Х	Х	Х	Х	Х	Х	Х	Х	Х		Х	Х	Х	Х	Х	Х
Check & Adjust Four Wheel Alignment ##	Х	х	х	х	х	х	х	х	х	х	х		Х	х	Х	Х	х	х

34 MAINTENANCE SCHEDULES

Years:	6 months	1	2	3	4	5	6	7	8	9	10	#10	11	12	13	14	15	16
Kilometers or time passed (whichever comes first)	5,000	15,000	30,000	45,000	60,000	75,000	90,000	105,000	120,000	135,000	150,000	#240,000	165,000	180,000	195,000	210,000	225,000	240,000
Check Engine Control System Operation (Using Electronic Diagnostic Interface)	х	х	х	х	х	х	х	х	х	х	х		х	x	х	х	x	х
Check and top-up battery demineralised water	х	х	х	х	х	х	х	х	х	х	х	х	х	х	Х	Х	х	Х

^{††} For AWD Vehicles Oil Change Frequency is 15,000 km / one year or Instrument Cluster Indication whichever is earlier. Customers should replace Engine Oil within 500 km of first indication in instrument cluster. Refer to relevant section of Owner's Manual for more details.

†† Change Engine Oil and Engine Oil Filter at every 10,000 km / one year whichever is earlier if using your vehicle under any of the severe duty conditions: Heavy, Urban, Short Trip.

* Regardless of the km covered, air filter should be replaced earlier if operating under dusty conditions.

It is recommended to flush and replace the engine coolant at the interval of 10 years/240,000 km or whichever comes first.

* Possible refill of the coolant may need to be completed using FCA recommended coolant after system integrity confirmations.

(**) Regardless of the distance covered, timing and accessory belts must be changed every four years for particularly demanding use (cold climates, city driving, long periods of idling) or at least every five years. Under no circumstances should these intervals be exceeded.

Wheel alignment & wheel balancing on chargeable basis.

AdBlue/Urea topup done during periodic mentainance is on chargeable basis.

Check and top-up battery demineralised water every six months.

Note : Maintenance not required for AGM Battery.

Before long journeys, check the following and top up if necessary:

1. Engine oil level

2. Engine coolant fluid level